

Figure 1




Figure 2




Figure 3




Figure 4




Figure 5A

112

114 FIRST NAME

116 MIDDLE NAME

118 LAST NAME

PIN

120 \*\*\*\*

122 SAVE PLAYER

Figure 6




Figure 5B




Figure 7A




Figure 8






Figure 7B



**Figure 9A**



**Figure 10**






Figure 9B








Figure 13A




Figure 13B




Figure 14A




Figure 14B




Figure 15A




Figure 15B

288

<b>HOPPER FILL INFORMATION</b>
<b>GAMING MACHINE IDENTIFIER</b>
<b>GAMING MACHINE ID</b>
<b>GAMING MACHINE LOCATION</b>
<b>GAMING DATE</b>
<b>GAMING SHIFT</b>
<b>VALUE</b>

**Figure 16A**

290

<b>FILL INFORMATION</b>
<b>GAMING MACHINE IDENTIFIER</b>
<b>GAMING MACHINE ID</b>
<b>GAMING MACHINE LOCATION</b>
<b>GAMING MACHINE NAME</b>
<b>GAMING DENOMINATION</b>
<b>GAMING DATE</b>
<b>GAMING SHIFT</b>

**Figure 16B**




Figure 17A




Figure 17B

488

**OPEN TABLE RATING FORM**

PLAYER NAME  
ZONE INFORMATION  
BANK INFORMATION  
SEAT IDENTIFIER  
ESTIMATED AVERAGE BET  
BET VALUE

**STATUS  
BUTTON**

Figure 18




Figure 19A





Figure 19B

Figure 20





330

<b>ALERT INFORMATION</b>
<b>TYPE</b>
<b>DATE / TIME</b>
<b>DEVICE</b>
<b>REPOSITORY</b>
<b>ZONE NAME</b>
<b>BANK NAME</b>
<b>DOCUMENT NUMBER</b>
<b>VALUE</b>
<b>POINTS</b>
<b>EMPLOYEE</b>
<b>ALERT MESSAGE</b>

Figure 22

500




Figure 23A




Figure 23B

506

POINT ADJUSTMENT REQUEST FORM	
TYPE :	
POINTS :	
REASON :	
CARD :	
<input type="button" value="ISSUE"/>	

Figure 24




Figure 25A

536

**PLAYER VOUCHERS FORM**

PATRON :  
CARD :  
TYPE :  
POINTS :  
VOUCHERS :

ISSUE

Figure 26




Figure 25B




Figure 27A

548

The form 548 is titled "VOUCHER INFORMATION FORM". It contains four lines of text: "VOUCHER ID:", "GOOD FOR:", "ISSUED ON:", and "EXPIRES ON:". At the bottom center of the form is a button labeled "CONTINUE".

Figure 28




Figure 27B




Figure 29A





Figure 30



**Figure 29B**